
尺寸: 70X100MM，材质：100g书纸，1C+1C，风琴折页

DRA-3543

25W Waterproof Portable Wireless Speaker



User manual

SAFETY PRECAUTIONS

Check that the voltage marked on the rating label matches your mains voltage.
Avoid extreme degrees of temperature, either hot or cold.
Place the unit well away from heat sources such as radiators or gas/electric fires.
Avoid exposure to direct sunlight and other sources of heat.
Charge the speaker at least once within three month to prevent the lithium battery from damaging of excessive consumption.
Always disconnect the unit from the mains power supply before connecting/ disconnecting other devices or moving the unit.
Unplug the unit from the mains power socket during a lightning storm.

Package Contents


Bluetooth Speaker x 1
Type C Cable X 1
Aux In Cable x 1
Instruction Manual x 1


Technical Data

Bluetooth Version: 5.0
Output : 25W (12.5W*2)
Battery: 2*2500mAh
Size: 192*74*74mm
Charging time:3-4h
Play time:3-10h（varies by volume level and content）

Product Overview

1.“⏻”
Long press: Power on/off
Short press: Play/Pause
2.“○”
Battery status LED indicator
3.“+”
Short press: Volume increase
Long press: Next track
4.“–”
Short press: Volume decrease
Long press: Previous track
5. “⋈”(TWS button)
6.“○”
Working status LED indicator
7.“✱”
Short press: Move to bluetooth mode
Answer/hang up the call
Long press: Reject the call
8.





Charging DRA-3543 Speaker

1. Connect to a PC/Laptop or any 5V USB adaptor with the USB cable included.
2. The Battery status LED will turn ON orange and keep blink to show you the electronic quantities. The battery indicator stays on after full charged.
3. Unplug the USB cable when fully charged.

Note: Speaker will prompt prompt “DUDU” tune when the battery power is low (<15%).

Starting DRA-3543 Speaker

1. After fully charged, long press the “⏻” button to turn on the speaker.
2. The green LED will start blinking.
3. It will turn itself off (power-saving) if idle for more than 20 minutes.
4. To manually turn off DRA-3543 speaker, long press the “⏻” button again.

Bluetooth Operation

1. Turn on the speaker, the green LED will start blinking.
2. Turn on the Bluetooth function of your mobile device and look for “ DRA-3543” in the Bluetooth device list.
3. After successfully connected the speaker will prompt a tone and the green LED will stop blinking.
4. Long press the “✱” button to disconnect the current Bluetooth connection.The speaker will prompt a tone and the green LED will start blinking.

Hands-free phone calls

1. Make sure the mobile phone is paired.
2. Press the “✱” button to answer the incoming phone call.
3. Press again to end the call.
4. Long press the “✱” button to reject the incoming phone call.


AUX IN Operation

1. Turn on the speaker, the green LED will start blinking.
2. Disconnect the paired mobile device with the speaker if they have been paired.
3. Use the 3.5mm audio cable provided to connect the speaker to an audio source,the green LED will stop blink.
4. You can play music from the audio source.

Note:

Short press the “✱” button during AUX IN operation, the speaker will move to Bluetooth mode.
You have to unplug and re-connect the audio cable to the speaker again to enter AUX IN mode.
The previous/next track button do not work during AUX IN mode.
Press the Play/Pause button to mute the speaker during music playback in AUX IN mode.

TWS(True Wireless Stereo) Pairing



1. Turn on: Press and hold the power on/off button to power on Speaker A and B. The LED light will turn on be blue and blinking, it means the speaker is into Bluetooth paring mode.
2. TWS mode: Short press the TWS button on one of them, the blue LED will be slow blink one this speaker, and the other one will still quickly blink.
3. Waiting for seconds, the speakers will be connected with each other.The speaker which was pressed will be the main speaker(left channel) and the other one will be the slave speaker(right channel).
4. Select Paring name: Find the Bluetooth list from device, select ‘DRA-3543’ and click it. The speaker will connected to the device. When you control the speaker by one speaker, the other one will be same. For example, when you increase the volume one right channel, the left channel will be also adjusted volume, and when you turn off the left channel, the right channel will also be turn off.
5. Disconnect TWS: Press and hold the TWS button, the TWS mode will be disconnected, and you can see the Bluetooth list on device, there will be two of ‘DRA-3543’.

Troubleshooting

Problem	Solution
No Power	Recharge the speaker.
No Sound	1. Adjust the volume on the connected device. 2. Make sure that your Bluetooth device is within the effective operational range.
Cannot find the pairing ID ‘DRA-3543’ on the Bluetooth device	1. Ensure the Bluetooth function is activated on your Bluetooth device. 2. Make sure that your Bluetooth device is within the effective operational range.