
D12说明书
折好纸后尺寸：75*100mm
材质：双铜纸 白底印黑字

DRA-3548
7W RGB Wireless Speaker w/Reflective Rope



User manual

what's in the box?



Bluetooth speaker*1




Type C charging cable*1



Instruction*1


Product figure

1.Light key
2.Volume"-" / Last song
3.Volume"+" / Next song
4.On/Off/Audio/Play/Pause
5.Charging indicator
6.Charging port
7.Mirco SD card(TF card)
8.Reset key




Bluetooth

1.Bluetooth connection




Long press	Turn on the speaker and Enter pairing mode Lighting is runing fast if bluetooth device not connected , use the bluetooth device to search for "DRA-3548" and click to connect.
Short press x2	Audio switch mode
and Short press	disconnect bluetooth device

2.Light mode




Short press x1	Lighting effect switch
Short press x2	Lighting on/off
Long press 5s	Start /Close alarm

3.Music control




/Short press x1	Volume"-"/"+"
/Long press	Last/Next song
Short press x1	Play/Pause

4.Answer the phone



Short press x1	Answer/Hang up
Long press	Reject call

Audio connection



Short press x2 Audio switch mode

When inserting audio devices , it will play the last insert one first.

Product charge



Red light on	The battery is charging
Red light off	Fully charged

To preserve battery lifespan, fully charge at least once every 45days

Specifications

Model	DRA-3548
Bluetooth version	V5.0
Product size	160*78*51mm
Bluetooth distance	≥10m (open distance)
Play time	4.5hours(100% volume with LED light on) 5.5hours(100% volume with LED light off) 10hours(50% volume with LED light off)
Play mode	BT/TF
Battery	1500mAh/3.7V
Charging input	DC 5V-1A
Speaker power	7W
Charging time	2.5H(battery empty status)
Distortion rate	THD<10%
Frequency response	20Hz-20KHz
The horn	50mm

Charging and battery information：

1.This product has a built-in non-removable and rechargeable battery. Please use the equipped Type-C cable to charge the battery.
2.The charging current voltage is 5V/1A, and the product can not be recharged with a charger of more than 5V/1A.
3.Please choose the charger that passes the regular manufacturer's safety certification.
4. Repeated charging on the speaker will cause battery performance degradation overtime, which is a normal phenomenon for all rechargeable batteries.

Warning：

Do not drop, disassemble, deform, modify or insert any objects into this product as operating damage may result.

Do not attempt to repair, modify or disassemble the product yourself. This product does not contain any user-serviceable components and may void the warranty.Do not clean the product with alcohol, ammonia based cleaners and abrasive cleaners.

Do not place this product in to contact with any sharp objects as this may cause scratches and operating damage.

Do not attempt to replace the product battery, it is built-in and is not user changeable.

Observe all signs and displays that require an electrical device or RF radio product to be switch off in designated areas.

Dispose of the product and the product's battery in accordance with local laws and regulations.

Do not place put flame source near the product.

Use the specialized adapter for charging.

Avoid using in damp or corrosive environment.

Do not touch metal or short circuit electrode.